







RUBIS




SET 1
2 SEATER LEFT + CORNER 90°
+ 2 SEATER RIGHT




SET 2 LEFT (or RIGHT)
2 SEATER LEFT (or RIGHT) + CORNER 90°
+ 2,5 SEATER RIGHT (or LEFT)





SET 3
2,5 SEATER LEFT + CORNER 90° + 2,5 SEATER RIGHT



SET 4 RIGHT (or LEFT)







SET 5 RIGHT (or LEFT)




UPHOLSTERY

FABRIC: FC - fix cover or LC - loose cover and LEATHER: FC - fix cover


FEET



STANDARD COMFORT



LUX COMFORT



PREMIUM COMFORT

